

iMettoS[®] Commercial Blender Instruction Manual



Model: BL-X

Please read this instruction manual carefully before operating this equipment

1.Safety Tips



Read this instruction manual before using and keep them available at all times!

Important Safeguards

1. Ensure the container is exactly on motor base before starting.
2. Please hold the container when it starts, as the motor is quite powerful. In addition, ensure the clutch is in place.
3. No tamper when starting the motor. Put cover on when using tamper.
4. To prevent the danger of the sharp blade, don't get food from the container by hand whether the container is put on the motor base.
5. Before pouring food out of the container, remove it from the motor base first.
6. Note if touching on/off switch carelessly before of after starting

2.Feature

This blender is equipped with an industrial powerful motor whose rotary speed is up to 25,000rpm. Dry or wet food can be quickly & efficiently into powder or mud, and its original nutrition and flavor still remained. It is a professional high-speed blender.


- Multi-use(en Closed with fruit & vegetable organic operation booklet)
- Industrial high-speed motor, high efficiency, powerful
- stainless steel & harden blade
- Using high quality tempered transparent plastic container, will not easily break(high temperature vulcanization treatment, food grade rubber cap, safe and hygiene is safeguarded)
- Important when using ice in the container do not start until all liquid ingredients are included.

3. Technical data


3.1 Technical specification

Name	Commercial Blender
Voltage	220-240 V/50 Hz
Capacity	2000c.c
Endurance of container	-40°C-180°C
Power	1500 W
Weight	4.2 kg
Length of cord	1.8 M
Dimension	W224.7*D224.7*H478.9mm
Protector	Current protector, Thermal protector for Motor

3.2 Overview of parts



3.3 Electric circuit



4. Operation Instruction

4.1 Operation

- 1) Make sure the left switch is locating at OFF
- 2) Connect the power, put the jug on the base before you have confirmed the cap is well covered on the jug.
- 3) Make the left switch locate at ON.
- 4) Set the speed adjustor to the suitable speed
- 5) If you want to made a higher speed, please push the PULSE switch on the right.

4.2 Safeguards

- 1) Unplug when the blender is not in use.
- 2) The cover can be open only when the blade agitator stops completely.
- 3) When cleaning, ensure to unplug first, the main base and the container must be washed separately.
- 4) Don't put the motor base in the water or the dishwasher.
- 5) When it's in use, keep the kids away and prevent Improper action of children to danger.
- 6) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid hazard.
- 7) No metal articles, such as knives, forks, spoons...etc in the container.
- 8) To prevent the danger of the cutting blade, don't clean by hand.

5. Maintenance Tips

- 1) When cleaning ,unplug & turn main switch off.
- 2) Clean the body& the cover with soft cloth
- 3) Don't clean inside of container by hand unless blade is already removed.
- 4) Clean the rotary shaft & the motor with dry cloth.
- 5) When it is not easy to remove dirt, clean with detergent and then wipe it by dry cloth.
- 6) For best results it is recommended to replace the blades yearly.

6.Trouble Shooting

Check if the circuit breaker button is turned off. Press it to reset if the blender still doesn't work. Please check the list in the following:

- 1) The power plug is inserted into the power outlet.
- 2) Use or automatic switch shuts off.

7.Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.

WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.

CAUTION!

For the disposal of the device please consider and act according to the national and local rules and regulations.

8.Warranty

iMettos warrants to the original purchaser of every new product, under normal and proper use and maintenance service as specified by iMettos and upon proper installation and start-up in accordance with the instruction packet supplied with each unit. iMettos' obligation under this warranty is limited to a period of one (1) year from the date of original installation.

WARRANTY CLAIMS

All claims for parts must be made directly through iMettos. All claims should include:

Personal Details:

Your name:

Your company:

Address:

Email:

Phone:

Products Details:

Model number:

Serial number of the product:

Date of purchase:

Proof of purchase :

Pertinent information supporting the existence of the alleged defect.(Such as picture etc.)

Please send the above information to services@imettos.co.uk

Our warranty departments will according to the actual situation and reply you within 24hours.



iMettoS Limited

www.imettos.co.uk